Saving a Position as a Waypoint:

From any NAV screen → MARK → MARK

Deleting a Waypoint:

From any screen → MENU → Select WAYPOINTS → ENTER → Select USER Category → Highlight waypoint to be deleted → ENTER → MENU → Select DELETE WPT → ENTER → Confirm → ENTER

Activating a GOTO:

GOTO → Select Category → ENTER → Select WPT → ENTER

Clearing a GOTO:

GOTO → MENU → Select CLEAR GOTO → ENTER

Accessing the Route Menu:

From any screen → MENU → Select ROUTES → ENTER

Creating a Route:

From any NAV screen → MENU → Select ROUTES → ENTER

Highlight empty route → MENU → Select CREATE → ENTER

ENTER → Select Category → ENTER → Select WPT

ENTER → Continue until route complete → MENU → Select SAVE ROUTE → ENTER

Reversing a Route:

MENU → Select ROUTES → ENTER → Select Route → MENU

Select REVERSE → ENTER

Deleting a Route:

From any screen → MENU → Select ROUTES → ENTER → Highlight route to be deleted

MENU → Select DELETE → ENTER → Confirm → ENTER